



9419 ANN ST. SANTA FE SPRINGS, CA. 90670 562-946-1907 (FAX) 562-946-5637

**Part# 52639698/52639699/  
52649698/52649698  
05-07 Chrysler 300 Wire Mesh Bumper Grille  
Installation Instructions**

**Hardware Kit:** (6) Nyloc Nuts (6) Flat Washers

Step 1: Remove the black plastic factory inserts from each of the bumper openings and remove any filler panels that may block access to the backside of the bumper openings. Save all hardware from any filler panels that are removed as it will be reused later.

Step 2: Test fit each of the wire mesh grilles into each of the bumper openings. It may be necessary to drill out the factory mounting locations to get the best fit and for ease of installation.

Step 3: Center each of the wire mesh grilles into each of the factory openings.

Step 4: Once you have centered each of the wire mesh grilles into their correct openings place the flat washers over each of the fully threaded studs and hold in place using the nyloc nuts.

Step 5: Take your time while securing the hardware. It is recommended to rotate tightening between the three studs on each grille to make sure that the grille is pulled into the pocket evenly and gives the best overall fit once all hardware has been secured.

Step 6: Replace any filler panels that were removed during the installation using the hardware that was saved from step 1.

**Installation Is Now Complete!!!!**